



# Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

## **PRO-LIFT # E30-82-085-01-20**

**1991-1997 Toyota Land Cruiser, 4WD, FJ80**

**Note: The Pro Truck Leveling springs must not be used with the OE shocks. Extended travel shocks are required to avoid damage to the suspension.**

Kit Contents	Description	Part Number	Qty
	Front Spring	F31-82-085-01-FA	2
	Instructions	E30-82-085-01-20INST	1

### **NOTES: Read All Instructions Before Beginning Installation**

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- Never use impact wrenches or impact guns to install or remove shock absorber piston components, shafts and piston rod nuts.
- **PRO-LIFT** springs should be installed with the Eibach Logo right side up. All original stock spring isolators, and tubing should be retained from the stock springs and used when installing the **PRO-LIFT** Springs.
- After installation, it is always important to inspect and adjust the following if necessary:
  - Wheel alignment such as camber, caster & toe
  - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
  - Brake line clearance and attachments
  - Brake anti-locking and anti-skid system sensors

### **Additional Eibach Components Available For Your Truck**

Eibach Kits	Part Number	Description	Front	Rear
<b>Pro Truck Sport front dampers</b>	E60-82-085-01-10	Off-Road Performance	+0-3"	N/A
<b>Pro Truck Sport rear dampers</b>	E60-82-085-01-01	Off-Road Performance	N/A	0-3"