

36457 Installation Instructions



1. Attach the 4 x 3 sleeve to the volant box and tighten the #64 clamp.

2. Slide the upper half of the scoop into the sleeve.



3. Align the rubber bumper with the existing hole on the frame.



4. Attach the bumper with the provided hardware.



5. Attach the remaining #64 clamp onto the upper half of the scoop.



6. Attach the 3.75 x 3.5 sleeve and lower scoop using the #60 clamps