

# Fast Fit 59850

**Ford**  
2011 - 2012 F150 5.0L

---

1. Disconnect the negative battery cable.
2. Loosen the clamp holding the duct to the throttle body and the clamp holding the duct to the air box.
3. Remove the breather hoses from the air duct than remove the duct.
4. Unsnap the MAF sensor harness from the sensor than remove the sensor from the air box.
5. Unsnap the clips from the air box than remove the box top and filter.
6. Attach the sensor into the Volant duct using the gasket and hardware provided.
7. Attach filter 5117 to the Volant system.
8. Attach the hump hose to the Volant duct and tighten the clamp.
9. Slide the Volant system onto the throttle body and clip the heat shield into place.
10. Tighten the Volant system to the throttle body.
11. Replace the factory crankcase breather hose with the supplied line and press the EVAP hose onto the Volant duct.
12. Clip in the MAF sensor harness onto the sensor.
13. Reattach the negative battery cable.

**Volant Cool Air Intakes Tech Support Line (909) 481-3888**

